HNC CANOPEN CONFIGURATION

Contents

1.Download and install driver	2
2. Wiring	2
2.1. Connect CAN	3
2.2. Connect CN1	3
3. Configuration	4
3.1. Reset encoder	5
3.2. Display all parameter	5
3.3. Set max speed during torque control	6
3.4. set encoder to maximum resolution	7
3.5. Enable CanOpen	9
3.6. Config filter	9
3.7. enable Force stop	10
3.8. disable prohibit for testing	11
3.9. Save paramters to Servo Driver	11
3.10. Restart servo	12


1.Download and install driver

http://www.hncelectric.com/en_download.aspx?cid=&category_id=0&page=2
there is a document too


Servo Drive	HSD7-E Servo Drive User Manual V0.3_202104	<u></u>
Servo Drive	HSD7 Commissioning Software-iWatch for 64bit OS	<u></u>
Servo Drive	HSD7 Commissioning Software-iWatch for 32bit OS	<u></u>

2. Wiring


LAN Connector




DB25 connector



CN1 Connector



The appearance when the connector housing is not installed as seen from the arrow direction is as follows.



2	PULS-	1	PULS+	27		26	-	
	FULS-	3	SIGN+	21		28	_	
4	SIGN-		OIOIV.	29	_	20		
		5	VREF+			30	TREF+	
6	VREF-	_		31	TREF-			
8	ALM-	7	ALM+	33	OUT3-	32	OUT3+	
0	ALIVI-	9	OUT1+	33	0013-	34	OUT4+	
10	OUT1-		00111	35	OUT4-		0014	
-		11	OUT2+			36	OUT5+	
12	OUT2-	42	DIGGIA	37	OUT5-	20		
14	IN0	13 DICOM	13	DICOM	39	IN4	38	-
ļ.,	IINU	15	IN1		1114	40	IN5	
16	IN2			41	IN6			
40		17	IN3	40		42	IN7	
18	-	19	PAO+	43	-	44	_	
20	PAO-	10	PAUT	45	_	77	_	
	PBO-	21 PBO+				46	-	
22				47	-	40		
24	PCO-	23 PCO+		49	_	48	-	
	. 00	25	GND	-10		50	-	
				l				

2.1. Connect CAN

Use LAN cable (20NM use CN3, 30 NM use CN4, can test which port can use)

CN3 or CN4	Description	DB25
1	CAN H	18
2	CAN L	6
3	GND	14


2.2. Connect CN1

Use at least 7 wires cable


CN1	Description	DB25
13	24V	1
14	Servo On	2
15	Force stop (E-Stop)	15
16	P-OT	8
17	N-OT	8
23	Z+	13
24	Z-	25

3. Configuration


- Use mini usb to USB connect servo driver to PC



- Open iwatch -> choose serial port (not port 1) -> seach -> choose device -> connect




- Click C/E to choose English



3.1. Reset encoder


If driver has alarm A.810 reset encoder.



→ Click "excecute" → power off driver → power on again.

3.2. Display all parameter

PN00B-> set "operator parameter display selection" too "display all parameters"




3.3. Set max speed during torque control


PN407 (here I set 150 rpm, you can choose from 120-200, depend on you :D)

	F				
ara	meter	s(PnXXX) Pn0XX Pn1XX Pn2X	XX Pn3XX	Pn4XX Pn5XX	Pn6XX
	No.	Name	Unit	Min/Max	Value
	Pn403	Reverse Torque Limit	1%*2	0~800	800
	Pn404	Forward External Torque Limit	1%*2	0~800	100
		Reverse External Torque Limit	1%*2	0~800	100
_		Emergency Chap Tangao	1% 2	0-000	000
	Pn407	Speed Limit during Torque Control	1 min-1	0~10000	150
	Pn4uo	Torque Public L'Emption Soloctions		0000~1111	000011
1	Hex0	Notch Filter Selection 1	-	-	0:Disable first stage notch filter.
-	Hex1	Speed Limit Selection	-	-	0:Use the smaller of the maximum motor speed and the setting of Pn407/Pn480 as the spee
1		Notch Filter Selection 2	-	-	0:Disable second stage notch filter.
		Friction Compensation Function Selecti	-	-	0:Disable friction compensation.
		First Stage Notch Filter Frequency	1 Hz	50~5000	5000
		First Stage Notch Filter Q Value	0.01	50~1000	70
		First Stage Notch Filter Depth	0.001	0~1000	0
		Second Stage Notch Filter Frequency	1 Hz	50~5000	5000
_		Second Stage Notch Filter Q Value	0.01	50~1000	70
_		Second Stage Notch Filter Depth	0.001	0~1000	0
_		Second Stage Second Torque Refere		100~5000	5000
_		Second Stage Second Torque Refere		50~100	50
		First Stage Second Torque Reference		0~65535	100
_		T-REF Filter Time Constant	0.01 ms	0~65535	0
		Torque-Related Function Selections 2		0000~1111	0000H
1	Hex0	Notch Filter Selection 3	-	-	0:Disable third stage notch filter.
1	Hex1	Notch Filter Selection 4	-	-	0:Disable fourth stage notch filter.
-		Notch Filter Selection 5	-	-	0:Disable fifth stage notch filter.
		Reserved parameter (Do not change.)		•	0:Reserved parameter (Do not change.)
	Pn417	Third Stage Notch Filter Frequency	1 Hz	50~5000	5000

3.4. set encoder to maximum resolution PN20E and PN210




Config encoder as single turn




3.5. Enable CanOpen

PN011: Hex 2 choose 800kbps, hex3 enable can open



3.6. Config filter

Enable filter and cutoff freq to 200hz



3.7. enable Force stop

	-			
Hex2	/PSELA (Reference Pulse Input Multiplication Switching Output) Signal	-	-	6:Disabled (the above signal output is not used).
Hex3	ALM (Alarm Output) Signal Allocation	-	-	0:Output the signal from the CN1-OUT0(7?8) output terminal.
Pn512	Output Signal Inverse Settings 1		0000~1111	0000H
Hex0	Output Signal Inversion for CN1-OUT9(8?9) Terminal	-	-	0:The signal is not inverted.
Hex1	Output Signal Inversion for CN1-OUT9(9?10) Terminal	-	-	0:The signal is not inverted.
Hex2	Output Signal Inversion for CN1-OUT2(11?12) Terminal	-	-	0:The signal is not inverted.
Hex3	Output Signal Inversion for CN1-OUT3(32?33) Terminal	-		0:The signal is not inverted.
Pn513	Output Signal Inverse Settings 2		0000~0011	0000H
Hex0	Output Signal Inversion for CN1-OUT4(34?35) Terminal	-	-	0:The signal is not inverted.
Hex1	Output Signal Inversion for CN1-OUT5(36?37) Terminal	-	-	0:The signal is not inverted.
Hex2	Reserved parameter (Do not change.)	-	-	0:Reserved parameter (Do not change.)
Hex3	Reserved parameter (Do not change.)	-	-	0:Reserved parameter (Do not change.)
Pn515	Input Signal Selections 6		0000~9999	0889H
Hex0	SEN (Absolute Data Request Input) Signal Allocation			9:The signal is always active.
Hex1	/PSEL (Reference Pulse Input Multiplication Switching Input) Signal All	-		8:The signal is always inactive.
Hex2	Reserved parameter (Do not change.)		-	8:Reserved parameter (Do not change.)
U _{ov} 2	Posoniod parameter (Do not obango)			9-Pasaniad parameter (Da not obango)
✓ Pn516	Input Signal Selections 7		0000~9999	1081H
Hex0	FSTP (Forced Stop Input) Signal Allocation		-	1:Active when CN1-IN1 input signal is ON (closed).
HexT	Reserved parameter (Do not change.)			8:Heserved parameter (Do not change.)
Hex2	Reserved parameter (Do not change.)	-	-	8:Reserved parameter (Do not change.)
Hex3	Reserved parameter (Do not change.)			8:Reserved parameter (Do not change.)
Pn517	Input Signal Inverse Settings 1		0000~1111	0000H
Hex0	Output Signal Inversion for CN1-IN0 Terminal	-	-	0:The signal is not inverted.
Hex1	Output Signal Inversion for CN1-IN1 Terminal	-	-	0:The signal is not inverted.
Hex2	Output Signal Inversion for CN1-IN2 Terminal	-	-	0:The signal is not inverted.


3.8. disable prohibit for testing

No.	Name	Unit	Min/Max	Value
Pn501	Zero Clamping Level	1 min-1	0~10000	10
Pn502	Rotation Detection Level	1 min-1	1~10000	20
Pn503	Speed Coincidence Detection Signal Output Width	1 min-1	0~100	10
Pn506	Brake Reference-Servo OFF Delay Time	10 ms	0~50	0
Pn507	Brake Reference Output Speed Level	1 min-1	0~10000	100
Pn508	Servo OFF-Brake Command Waiting Time	10 ms	10~100	50
Pn509	Momentary Power Interruption Hold Time	1 ms	20~50000	20
Pn50A	Input Signal Selections 1		0000~9991	8801H
Hex0	Input Signal Allocation Mode	-		1:Change the sequence input signal allocations.
Hex1	/S-ON (Servo ON) Signal Allocation	-	-	0:Active when CN1-IN0 input signal is ON (closed).
Hand	(D.COM (Desperties of Control) Cignal Allegation			O.The eigent in abusys in estima
Hex3	P-OT (Forward Drive Prohibit) Signal Allocation	-	-	8:Set the signal to always enable forward drive.
Pn50B	Input Signal Selections 2		0000~9999	8888H
Hex0	N-OT (Reverse Drive Prohibit) Signal Allocation	-	-	8:Set the signal to always enable reverse drive.
Hex1	/ALM-RST (Alarm Reset) Signal Allocation	-	-	8:The signal is always inactive.
Hex2	/P-CL (Forward External Torque Limit Input) Signal Allocation	-	-	8:The signal is always inactive.
Hex3	/N-CL (Reverse External Torque Limit Input) Signal Allocation	-	-	8:The signal is always inactive.
Pn50C	Input Signal Selections 3		0000~9999	8888H
Hex0	/SPD-D (Motor Direction) Signal Allocation	-	-	8:The signal is always inactive.
Hex1	/SPD-A (Internal Set Speed Selection Input) Signal Allocation	-		8:The signal is always inactive.
Hex2	/SPD-B (Internal Set Speed Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
Hex3	/C-SEL (Control Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
Pn50D	Input Signal Selections 4		0000~9999	8888H
Hex0	/ZCLAMP (Zero Clamping Input) Signal Allocation	-	-	8:The signal is always inactive.
	(INITIDIT (Defended Dales Inhibit Innut) Const Allegation	-	-	8:The signal is always inactive.
Hex1	/INHIBIT (Reference Pulse Inhibit Input) Signal Allocation			

After testing work change like this

		Tiumo .	OT III.	CHILD COME	1000
	Pn501	Zero Clamping Level	1 min-1	0~10000	10
	Pn502	Rotation Detection Level	1 min-1	1~10000	20
	Pn503	Speed Coincidence Detection Signal Output Width	1 min-1	0~100	10
	Pn506	Brake Reference-Servo OFF Delay Time	10 ms	0~50	0
	Pn507	Brake Reference Output Speed Level	1 min-1	0~10000	100
	Pn508	Servo OFF-Brake Command Waiting Time	10 ms	10~100	50
	Pn509	Momentary Power Interruption Hold Time	1 ms	20~50000	20
$\overline{\mathbf{v}}$	Pn50A	Input Signal Selections 1		0000~9991	2801H
	Hex0	Input Signal Allocation Mode	-	-	1:Change the sequence input signal allocations.
	Hex1	/S-ON (Servo ON) Signal Allocation		-	0:Active when CN1-IN0 input signal is ON (closed).
	Hev?	/P.COM (Proportional Control) Signal Allocation			8:The signal is always inactive
	Hex3	P-OT (Forward Drive Prohibit) Signal Allocation		-	2:Enable forward drive when CN1-IN2 input signal is ON (closed
⊡	Pn50B	Input Signal Selections 2		0000~9999	8883H
•	Hex0	N-OT (Reverse Drive Prohibit) Signal Allocation	-	-	3:Enable reverse drive when CN1-IN3 input signal is ON (closed
	нехт	/ALM-RST (Alarm Reset) Signal Allocation	-	-	8: The signal is always inactive.
	Hex2	/P-CL (Forward External Torque Limit Input) Signal Allocation	-	-	8:The signal is always inactive.
	Hex3	/N-CL (Reverse External Torque Limit Input) Signal Allocation	-	-	8:The signal is always inactive.
	Pn50C	Input Signal Selections 3		0000~9999	8888H
	Hex0	/SPD-D (Motor Direction) Signal Allocation	-	-	8:The signal is always inactive.
	Hex1	/SPD-A (Internal Set Speed Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
	Hex2	/SPD-B (Internal Set Speed Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
	Hex3	/C-SEL (Control Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
	Pn50D	Input Signal Selections 4		0000~9999	8888H
	Hex0	/ZCLAMP (Zero Clamping Input) Signal Allocation	-	-	8:The signal is always inactive.
	Hex1	/INHIBIT (Reference Pulse Inhibit Input) Signal Allocation		-	8:The signal is always inactive.
	Hex2	/G-SEL (Gain Selection Input) Signal Allocation	-	-	8:The signal is always inactive.
					>

3.9. Save paramters to Servo Driver



3.10. Restart servo